


USB PLUG

Channel A


Channel B



USB RECEPTACLE

Channel D


Channel C



USB PLUG

Channel D

Channel C



USB RECEPTACLE

Channel A

Channel B

Power Supply

