






XDFN2 1.0x0.6, 0.65P (SOD-882) CASÉ 711AM ISSUE O

DATE 29 AUG 2012








BOTTOM VIEW

RECOMMENDED **SOLDER FOOTPRINT***



*For additional information on our Pb-Free strategy and soldering details, please download the **onsemi** Soldering and Mounting Techniques Reference Manual, SOLDERRM/D.

NOTES:

- DIMENSIONING AND TOLERANCING PER
- ASME Y14.5M, 1994.

 CONTROLLING DIMENSION: MILLIMETERS.

 EXPOSED COPPER ALLOWED AS SHOWN.

	MILLIMETERS		
DIM	MIN	MAX	
Α	0.34	0.44	
A1		0.05	
b	0.43	0.53	
D	1.00 BSC		
Е	0.60 BSC		
е	0.65 BSC		
L	0.20	0.30	

GENERIC MARKING DIAGRAM*



XX = Specific Device Code

= Date Code

= Pb-Free Package

*This information is generic. Please refer to device data sheet for actual part marking. Pb-Free indicator, "G", may or not be present.

DOCUMENT NUMBER:	98AON82886E	Electronic versions are uncontrolled except when accessed directly from the Document Repository. Printed versions are uncontrolled except when stamped "CONTROLLED COPY" in red.	
DESCRIPTION:	XDFN2 1.0X0.6, 0.65P (SOD-882)		PAGE 1 OF 1

onsemi and ONSEMI are trademarks of Semiconductor Components Industries, LLC dba onsemi or its subsidiaries in the United States and/or other countries. onsemi reserves brisefin and of 160 m are trademarked so defined values of services and of the confined values and of the values of the confined values and of the values of the confined values and of the values of the v special, consequential or incidental damages. onsemi does not convey any license under its patent rights nor the rights of others.