

MECHANICAL CASE OUTLINE



SOLDERING FOOTPRINT*



GENERIC MARKING DIAGRAM*



XXXXX = Specific Device Code

XXXXX = Specific Device Code Y = Year

Y = Year

Y = Year M = Month

DD = Additional Traceability Data

XXXXXX

YDD

DDD = Additional Traceability Data

*This information is generic. Please refer to

NOTE: The measurements are not to guarantee but for reference only.

*For additional information on our Pb-Free strategy and soldering details, please download the ON Semiconductor Soldering and Mounting Techniques Reference Manual, SOLDERRM/D.

may or may not be present.

device data sheet for actual part marking. Pb-Free indicator, "G" or microdot " •",

| DOCUMENT NUMBER: | 98AON78678E | Electronic versions are uncontrolled except when accessed directly from the Document Repository. Printed versions are uncontrolled except when stamped "CONTROLLED COPY" in red. | |
|------------------|---------------------|---|-------------|
| DESCRIPTION: | VCT16 2.6X2.6, 0.5P | | PAGE 1 OF 1 |

ON Semiconductor and are trademarks of Semiconductor Components Industries, LLC dba ON Semiconductor or its subsidiaries in the United States and/or other countries. ON Semiconductor reserves the right to make changes without further notice to any products herein. ON Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does ON Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation special, consequential or incidental damages. ON Semiconductor does not convey any license under its patent rights nor the rights of others.