



Test Procedure for the NCP718SNT1GEVB Evaluation Board

There is a collection test procedures for NCP718 demo boards. This paper offers some helpful test configuration for first contact with ONSEMI NCP718 LDO.

1. QUIESCENT CURRENT




Figure 1: Test configuration for measurement I_Q , Quiescent Current

1. Connect circuit as shown figure on 1.
2. Apply voltage at V_{Input} . Default test V_{input} is $V_{out_nom}+1V$ or $2.5V$ whichever is greater.
3. Value shown μA meter is measured quiescent current.
4. Measurement is finished. Disconnect supply voltage.

**Note – Be carefully if any device is connected on output, because leakage current can affect measurement accuracy.*

2. LOAD REGULATION




Figure 2: Test configuration for measurement REG_{LOAD} , Load Regulation



1. Connect circuit as shown figure on 2.
2. Apply voltage at V_{Input} . Default test V_{Input} is $V_{\text{out_nom}}+1\text{V}$ or 2.5V whichever is greater.
3. Set minimal required current I_1 , e.g. 1mA , and switch load ON.
4. Note the value V_1 from voltmeter V .
5. Switch load OFF and set maximal required current I_2 , e.g. 250mA and switch load ON.
6. Note the value V_2 from voltmeter V .
7. Load regulation is obtained via following formula: $\text{REG}_{\text{LOAD}}=(V_1-V_2)$, [V]
8. Measurement is finished. Disconnect supply voltage.

3. LINE REGULATION




Figure 3: Test configuration for measurement REG_{LINE} , Line Regulation

1. Connect circuit as shown on figure 3.
2. Set load to the required current e.g. 10mA .
3. Set minimal input voltage V_{I1} , $V_{\text{OUT_NOM}}+1\text{V}$ or 2.5V whichever is greater.
4. Note the value V_{I1} and V_{O1} .
5. Set maximal input voltage $V_{I2} = 24\text{V}$.
6. Note the value V_{I2} and V_{O2} .
7. Load regulation is obtained via following formula: $\text{REG}_{\text{LINE}}=(V_{O1}-V_{O2})/(V_{I1}-V_{I2})$, [V/V]
8. Measurement is finished. Disconnect supply voltage.



4. ENABLE START-UP




Figure 4: Test configuration for measurement enables response

1. Connect circuit as shown on figure 4.
2. Set generator to SQUARE PULSE, $0.9V \leq AMPLITUDE \leq V_{IN}$, FREQUENCY=10Hz, DUTY=10%.
3. Apply voltage at V_{Input} . Default test V_{input} is $V_{out_nom} + 1V$ or $2.5V$ whichever is greater.
4. Set required I_{OUT} , e.g. 10mA.
5. Connect oscilloscope to EN signal and V_{OUTPUT} .
6. Watch enable response of the regulator after asserting EN pin.
7. Measurement is finished. Disconnect supply voltage.