



ON Semiconductor

Test Procedure for the NCP1032BGEVB Evaluation Board




Figure 1: Test Setup

The following steps describe the test procedure for all these boards:

Suggested Equipment:

- Current limited DC Power Supply (e.g. Sorensen XHR150-7) 1pc
- DC Volt-Meter able to measure up to 60 V DC (e.g. KEITHLEY 2000) 2pcs
- DC Amp-Meter able to measure up to 2 A DC (e.g. KEITHLEY 2000) 1pc
- DC Amp-Meter able to measure up to 5 A DC (e.g. FLUKE 89 IV)..... 1pc
- DC Electronic Load (e.g. AGILENT 6060B) 1pc

Test Procedure:

1. Connect the test setup as shown in Figure 1.
2. Apply an input voltage, $V_{IN} = 48\text{ Vdc}$
3. Apply $I_{OUT}(\text{load}) = 0\text{ A}$
4. Observe Soft start
5. Check that $V_{OUT} = 12\text{ V} \pm 5\% \text{ Vdc}$
6. Set I_{OUT} to desired level 0 A- 100 mA and measure voltage and current the efficiency should be similar to that shown in Figure 2
7. Turn off the load
8. Turn off V_{IN}
9. End of the test




Figure 2 Efficiency